

Camera Accessories by Richard Franiec
Mounting Instructions for the Sony RX100 Custom Grip

Dear Fellow Sony RX100 Owner,

Thank you for choosing my Custom Grip (CG-RX100) for your camera.

Please review these mounting instructions carefully before attaching the grip to the camera to avoid problems associated with improper mounting.

Once it's on, you'll enjoy the better, more secure feeling when handling your RX100, even one-handed.

To mount the grip to the camera, please follow the steps below:

1. Dry Run – perform the “dry run” below so you understand the position the grip should be in for final mounting:

- Leave the backing material on the VHB clear transfer tape – do not remove.
- Take the battery out of the camera and close the battery door.
- Slide the grip toward the lens until the curved lip of the grip comes in contact with the rounded side of the camera.
- Gently slide the grip up or down to achieve position in between top and bottom of camera. On each side top and bottom of the grip should coincide with the end of small radius on top and bottom of the front body plate. Gently press the grip down until it sits flat on the camera.
- This is the reference position for proper placement of the grip.
- Repeat this step until you know the right position.
- For a visual reference of properly mounted grip, please, visit:
<https://picasaweb.google.com/RichardFraniec/SupplementToRX100MountingInstructions?authkey=Gv1sRgCN6erYSxtvDSaA>

2. Use rubbing alcohol (not included) to remove any impurities and skin oils from the mounting surface area on the camera. Wipe dry.

3. Peel the backing material from the tape. Don't touch the sticky side with your fingers.

4. Hold the grip just above the correct position **without touching the camera**. You will not be able to freely slide the grip once it makes contact with the camera – so be sure it's just above where you want it. Then very gently put it in place.

Don't apply pressure at this time. You can't slide the grip, but you can make minor adjustments and you can pull it off the camera to reposition it. Take your time and do it right.

5. Once you're satisfied with the placement, press the grip down and from the side firmly.

6. Your grip is now attached.

For best results, press the grip in several different spots to ensure a uniform bond. Always press straight down towards the camera body.

After affixing the grip, let it sit for about 30 minutes before handling it. The full-strength bond takes effect within several hours.

*Note: The adhesive used for mounting the CG-RX100 has exceptional holding power when the grip is mounted properly on the camera. Regardless of that, use of a wrist or neck strap is highly recommended to ensure complete safety. The grip can be safely removed if you **really** need to by using dental floss to separate grip from the body.*

Thanks again – I hope you enjoy your new CG-RX100 grip.

Sincerely,

Richard Franiec